



# HEIGHT ADJUSTABLE UMBRELLA CLAMP INSTRUCTION MANUAL



Stay cool, dry, and hands-free wherever you go! This Adjustable Umbrella Clamp Holder attaches easily to your wheelchair, scooter, bike, stroller, or chair, keeping your umbrella secure while you move or relax outdoors.

The telescopic design lets you adjust the height, and the base allows for small angle adjustments to get your shade or coverage just right. It's sturdy, simple to use, and perfect for keeping your hands free on the go.

## Great for:

- Wheelchairs, mobility scooters, and walkers
- Bikes, strollers, and outdoor chairs
- Hands-free protection from sun or rain
- Supporting independence and comfort outdoors
- Strollers or prams for family outings
- Outdoor activities like markets, fishing, or picnics

## Features:

- Hands-free design, ideal for those with limited grip or hand mobility
- Adjustable height and secure base clamp for light angle positioning
- Durable stainless steel and reinforced plastic for stability
- Extends up to approx. 45 cm
- Weather-resistant and lightweight for everyday use
- Available in a range of colours
- Helps reduce strain by removing the need to hold an umbrella
- Simple screw-style fittings for easy attachment and removal

**Image description:** Photos show the umbrella clamp holder in red, blue, green, and black, attached to bikes, mobility scooters, and strollers. The adjustable rod securely holds an umbrella above for hands-free shade or rain protection.



# HEIGHT ADJUSTABLE UMBRELLA CLAMP

## INSTRUCTION MANUAL

### Details:

**Material:** Stainless Steel + ABS Plastic

**Size:** Please see below...

**Folded Down:** Approx 30cm (L)

**Extended to:** 45cm

**Handle Bar Clamp:** To fit 2 - 2.5cm handlebar

**Weight:** 260 grams approx

**Package Includes:** 1x Umbrella Clamp

**Age Guidance:** Suitable for adult use on wheelchairs, prams, strollers, mobility scooters, bikes, and outdoor chairs. Younger users may use when installed by an adult and with supervision. Not intended as a toy.

### How to use:

1. Open the clamp and position it around a stable bar, handle, or frame
2. Tighten the clamp until it feels secure and does not move
3. Insert the umbrella handle into the top holder
4. Tighten the top grip to hold the umbrella firmly in place
5. Adjust the telescopic rod to raise or lower the umbrella height
6. Rotate or angle the holder slightly to position your shade or rain cover
7. Double check everything is secure before moving or heading outdoors

### Care Instructions:

- Wipe clean with a damp cloth if exposed to dirt, dust, or rain
- Allow to dry fully before storing to help prevent rust or wear
- Check screws and fittings regularly to ensure they remain tight
- Avoid forcing the joints or over-tightening clamps
- Store in a dry place when not in use