



# ELECTRIC JAR OPENER INSTRUCTION MANUAL



Jar lids can be stubborn at the best of times, and when your hands are not feeling their strongest, opening one can quickly shift from a quick task to something you would rather avoid.

Meet the Electric Jar Opener. It does the twisting for you. No tapping the jar, no prying at the lid with a spoon, and no needing someone else to step in. Place it on top, press the button, and it gets to work. The lever adjusts to grip both the jar and the lid, then rotates until the seal releases before resetting, ready for next time.

This jar opener is a straightforward tool that gives your wrists and fingers a break when you need it, or simply makes opening jars easier.

## Great for:

- Opening tight jar lids without straining your hands
- Reduced grip strength or difficulty twisting lids
- Arthritis, sore joints, or hand and wrist pain
- Fatigue, low energy days, and pacing your strength
- Tremors or shaky hands
- One-handed support and upper-body mobility challenges
- Older adults wanting a safer, easier kitchen tool
- Everyday convenience for busy households
- Recovery after surgery or injury
- Supporting independence in the kitchen

## Features:

- Electric, hands-free jar opening
- One-button operation
- Automatically rotates around the lid to open it
- Helps reduce pain and strain on wrists and fingers
- Durable ABS plastic body with alloy steel parts
- Great for daily kitchen use
- Battery powered for easy use anywhere



# ELECTRIC JAR OPENER INSTRUCTION MANUAL

**Image Description:** A white electric jar opener with a green button is shown gripping the lid of a jar. The opener sits on top of the jar and clamps around the lid, designed to automatically twist and open the lid with the push of a button.

## Details:

**Materials:** ABS Plastic, Alloy Steel

**Size:** 18cm (L) x 6.3cm (W) x 11cm (H)

**Working Voltage:** DC2.4-3V

**Battery Requirements:** 2x AA Batteries (not included)

**Weight:** 335 grams

**Package Contains:** 1x Electric Jar Opener + Manual

## How to Use:

1. Locate the battery compartment cover on the back of the device. Press down and pull it out to open. Insert 2 AA batteries, then slide the cover back into place.
2. Set the device directly on top of the jar lid.
3. Press and hold the green button. The outer grips will move inward to secure the jar, while the inner grips will tighten around the lid.
4. Once the grips have a firm hold, they will automatically rotate to twist the lid open.
5. Wait for the grips to finish their rotation and return to their original, wide position. Once the motor stops, you can lift the opener away and simply pick up the loosened lid.

## Care Instructions:

- Wipe clean with a damp cloth.
- Dry with a new cloth, or air dry completely before putting away.
- If the device starts to slip during use, wipe the rubber grips and the jar lid with a dry cloth to remove any dust or oily residue.
- **Never** immerse the unit in water or place it in the dishwasher. The internal motor and battery compartment are not waterproof.
- If necessary, use a tiny amount of gentle, non-abrasive soap. Avoid harsh chemicals or scouring pads that could scratch the surface.